

Title 13AIRPORTChapters:13.04 Administration and RegulationChapter 13.04ADMINISTRATION AND REGULATIONSections:

- 13.04.010 Airport manager--Appointment--Duties.
- 13.04.020 Air traffic rules--Conformance required.
- 13.04.030 Air traffic rules--Federal regulations to govern.
- 13.04.040 Commercial use--Permission required.
- 13.04.050 Sale of food or commodities--Permission required.
- 13.04.060 Suspension of flight operations--Authority.
- 13.04.070 Plane line designation authority.
- 13.04.080 Landing and takeoff--Safe distance required.
- 13.04.090 Taxiing after landing.
- 13.04.100 Taxiing in or out of hangars prohibited.
- 13.04.110 Parking of unhused aircraft.
- 13.04.120 Wheel blocking required--Exception.
- 13.04.130 Starting, warmup of aircraft engines--Restrictions.
- 13.04.140 Starting, operating--Without competent person prohibited.
- 13.04.150 Starting, operating--Signals required.
- 13.04.160 Use of aircraft while intoxicated prohibited.
- 13.04.170 Operation of aircraft engines in hangar prohibited.
- 13.04.180 Fueling of engine while operating prohibited.
- 13.04.190 Owner's duty to dispose of damaged aircraft.
- 13.04.200 Repair to aircraft.
- 13.04.210 Mechanical work to be performed in repair shop.
- 13.04.220 Automobile parking restricted.
- 13.04.230 Smoking restricted.
- 13.04.240 Violation--Penalty.

13.04.010 Airport manager--Appointment--Duties. The city manager shall appoint a manager of the municipal airport of the city, who shall be charged with the enforcement

of this chapter and with the proper operation of the airport. (Prior code §2-101).

13.04.020 Air traffic rules--Conformance required. It is unlawful for any person to navigate any aircraft from, to or over the municipal airport otherwise than in conformity with the air traffic rules as established by any agency of the United States having jurisdiction over said matters. (Prior code §2-102).

13.04.030 Air traffic rules--Federal regulations to govern. In the event there shall be any conflict between the provisions of this chapter and the rules and regulations established by any federal agency having jurisdiction, the federal rules shall apply. All persons using the airport must conform to such federal rules and regulations. (Prior code §2-123).

13.04.040 Commercial use--Permission required. No person, firm or corporation shall use the municipal airport as a base, or terminal, for the operation of any type of commercial aviation, or for the transportation of passengers, freight, express or mail for hire, or for commercial flight instruction, or for communications, without first having secured permission therefor from the governing body as provided in KSA 3-117. Nothing in this section shall be construed to apply to any transport aircraft for the transportation of passengers or mail operating on a schedule of federal airways. (Amended during 1977 codification: prior code §2-103).

13.04.050 Sale of food or commodities--Permission required. No person shall engage in the sale of refreshments, food or any other commodity within the confines of the municipal airport without previously having secured permission therefor from the governing body as provided in KSA 3-116. (Amended during 1977 codification; prior code §2-104).

13.04.060 Suspension of flight operations--Authority. The airport manager shall have authority to suspend flying operations on or from the municipal airport, except in the event of scheduled operations, when in his opinion, the conditions of the landing area or local meteorological conditions make such operations unsafe. (Prior code §2-108).

13.04.070 Plane line designation authority. The plane line shall be designated by the airport manager. (Prior code §2-119).

13.04.080 Landing and takeoff--Safe distance required. All aircraft shall land and take off a safe distance from the hangars and other buildings, obstacles, areas reserved for spectators, and areas designated for the parking of automobiles about the airport. (Prior code §2-107).

13.04.090 Taxiing after landing. Every pilot landing an aircraft at the municipal airport shall first assure himself that there is no danger of collision with other aircraft taking off, landing or taxiing before and while taxiing to the line or other part of the airport. All aircraft shall be taxied at a slow and reasonable speed, particularly in the vicinity of hangars and other buildings, and shall be brought to a full stop when in the vicinity of other aircraft in the process of landing. (Prior code §2-109).

13.04.100 Taxiing in or out of hangars prohibited. No aircraft shall be taxied into or out of hangars. (Prior code §2-110).

13.04.110 Parking of unhoued aircraft. All unhoued aircraft shall be parked in the space designated for that purpose, and shall be firmly secured to the ground by ropes and stakes, or otherwise, when left unattended or during weather conditions which indicate the necessity therefor. Owners of such aircraft shall be held liable for any damage resulting from failure to properly comply with this section. (Prior code §2-118).

13.04.120 Wheel blocking required--Exception. Blocks or chocks shall be placed in front of the wheels of all aircraft being operated at the municipal airport before the engine of such aircraft is started, unless the aircraft is provided with adequate brakes. (Prior code §2-112).

13.04.130 Starting, warmup of aircraft engines--Restrictions. Aircraft shall be started and warmed up only in the places designated for such purposes by the airport manager. At no time shall engines be tuned up in such position that hangars, shops, or other buildings, or any group of people in the observation area, shall be in the path of the propeller stream. (Prior code §2-117).

13.04.140 Starting, operating--Without competent person prohibited. No aircraft engine shall be started or operated unless a competent person is in the cockpit attending the controls. (Prior code §2-113).

13.04.150 Starting, operating--Signals required. In the starting and operation of any aircraft engine the customary procedure shall be used by the person operating the

starting device and the person at the engine controls. All challenges and signals between the two shall be clearly understood, and so indicated by repetition before action is taken by either. (Prior code §2-116).

13.04.160 Use of aircraft while intoxicated prohibited. No person shall take any aircraft from the landing area or hangars or attempt to operate such aircraft while under the influence of intoxicating liquor. (Prior code §2-111).

13.04.170 Operation of aircraft engines in hangar prohibited. No aircraft engines shall be operated in any hangar except upon express permission of the airport manager. (Prior code §2-114).

13.04.180 Fueling of engine while operating prohibited. No aircraft shall be fueled while the engine is operating. (Prior code §2-115).

13.04.190 Owner's duty to dispose of damaged aircraft. The owner of any aircraft, or his pilot or agent, shall be responsible for the prompt removal and disposal of wrecked or damaged aircraft, and the parts thereof, from the traveled portion of the airport, so as to avoid interference with field operations. (Prior code §2-105).

13.04.200 Repair to aircraft. All repairs to aircraft and aircraft engines shall be made in the spaces designated for that purpose, and shall not be made on the area reserved for landings and takeoffs. (Prior code §106).

13.04.210 Mechanical work to be performed in repair shop. All mechanical work, except inspection, removal and replacement of parts, shall be performed only in the repair shop, and shall not be performed in the storage area of hangars. (Prior code §2-122).

13.04.220 Automobile parking restricted. The operators of automobiles and other vehicles, except only the drivers of vehicles regularly employed in the service of the airport, shall use no portion of the airport except the regularly designated drives and parking areas. (Prior code §2-120).

13.04.230 Smoking restricted. No person shall smoke in any hangar or in any room or building on the airport, except in offices, waiting rooms or buildings in which smoking is specifically authorized. (Prior code §2-121).

13.04.240 Violation--Penalty. Any person violating any of the provisions of this chapter shall, upon conviction thereof, be fined in any sum not to exceed \$100.00. (Prior code §2-124).